

cersanit



RU инструкция по монтажу и эксплуатации настенных смесителей

PL instrukcja montażu i obsługi baterii ściennych

EN installation and operation manual for wall-mounted faucets

KK qabyrgalyq aralastyrgyshtarga arналған montajday және ekspliyatsiia бойynsha nusqaylyq

AZ divardan asılan su kranlarının quraşdırılması və istismarı üzrə təlimat

UZ devorga ilinadigan smesitellarni o'rnatish va foydalanish bo'yicha yo'riqnom

KG lyubalga asma chabyshtrygchty ornottuy jana ishtettyu boyncha nuska










KA გველის ზეზრვის მონტაჟის და ექსპლუატაციის ინსტრუქცია

TK divar garyjlyary gurnamak we ulanmak boyunça gözükdirme

HY Պատե ծորակների տեղադրման և շահագործման հրահանգ


TJ дастурамал оид ба насбкунӣ ва истифодабарии омехтакунандаҳои деворӣ

MN ханын ус холигч угсрах ба ашиглах заавар




5A


$H_2O +$ SOAP +






B




C




7D




A




B



C



A



B

