

cersanit

RU инструкция по монтажу и эксплуатации вертикальных смесителей

PL instrukcja montażu i obsługi baterii pionowych

EN installation and operation manual for vertical faucets

KK vertikal aralastygysharga arналган montajday және ekspluatatsia бойынша nusqaylyq

AZ vertikal su kranlarının quraşdırılması və istismarı üzrə təlimat

UZ vertikal smesitellarni o'rnatish va foydalanish bo'yicha yo'riqnomasi

KG тикелей чабыштыргычты орнотуу жана иштетүү боюнча нускама




KA ვერტიკალური შეზღვევის მონტაჟის და ექსპლუატაციის ინსტრუქცია

TK dik garyjylary gurnamak we ulanmak boýunça gözükdirme

HY Ուղղահայաց ձուրակների տեղադրման և շահագործման հրահանգ

TJ дастурамал оид ба насбкунӣ ва истифодабарии омехтакунандаҳои амудӣ

MN босоо ус холигч угсрах ба ашиглах заавар



CERSANIT THERMO-BLOCK

